



Sunflower II

Technical Dimensions:

When people see Sunflowers in real (3D), they feel Sunflowers look bigger than in 2D. By the same token, even though there seems to be not much difference in 2D between Sunflower 1 & 2, there is a big difference in size if you see them actually.

Sunflower II LED

- (1) Head length: 235mm (9.25")
- (2) Head top diameter: 131mm (5.16") phi
- (3) Head bottom diameter: 134mm (5.28") phi

Flexible Stand

- (1) Flexible stand diameter: 25mm (.98") phi
- (2) Flexible stand length: 460mm (18.11")

Clamp type base

- (1) Minimum table surface from the edge: 47mm (1.85")
- (2) Maximum table thickness: 50mm (1.97")
- (3) Total extended length below table surface (maximum room below table surface): 150mm (5.91")
- (4) Length above table surface: 33mm (1.30")

Screw Down Mount (Optional)

- (1) Minimum table surface: 3.94"(100mm) phi
- (2) Length above the table surface: 1.81"(46mm)

Portable Stand (Optional)

- (1) Base size: 20" x 20" x 6"
- (2) Column Length: 17"
- (3) Shortest height without Sunflower: 22.50"
- (4) Longest height without Sunflower: 33"
- (5) Normal installation of Sunflower: 17.5" height
- (6) Shipping Box Size: 20" x 20" x 6"
- (7) Shipping Weight: 8LB

FILTERS

Sunflower II filters consist of 2 plies cloth filters:

- (1) Outer one is made of black carbon activated filter which is good for reducing smell and collecting dust.
- (2) Inner filter is for not only collecting dust but also controlling air flow.

Suction power is directly related to the filter thickness and various gel or acrylic ingredients.

If filters seem to be too thick or dense for air flow, just take out the inner filter for the better air passage

Filter should be cleaned everyday or more often in a busy day for the better result.

To clean filters, users can clean the filters with a regular vacuum, or tap them outside building.

Each box contains two sets of filters, one set of filter in the machine and one extra set of filter.

On busy day, a user can use one filter in the morning and the extra in the afternoon and clean them both at the end of the day.

Or user can buy 1 pack of filters which includes 1 pack(5 filters) to use filters sparingly.